HOW TO ADJUST YOUR CONTROL CHAIR



REAR RIGHT LEVER SEAT ANGLE

Turn forward for a forward tilt seat position.

Turn back for a level seat position.

ROUND RIGHT HANDLE SEAT/ BACK TILT TENSION

Turn forward to increase tension. Turn backward to lighten tension.

FRONT RIGHT LEVER GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.

Take your weight off the seat and lift lever to raise the gaslift.

ADJUSTABLE HEADREST

Slide up to adjust height. Twist in or out to adjust angle.

> HEIGHT-ADJUSTABLE ARMRESTS Use button on side of armrest to adjust height.

Turn forward to release seat/back synchro tilt.

> Turn backward to lock in desired position.

FRONT LEFT LEVER

Take your weight off the seat, lift lever, and slide seat forward or backward to adjust position.

f the seat e the gaslift. EDEN CONTROL





SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust the tilt tension so that when the synchro tilt is released the chair supports your weight in an upright seated position but allows you to lean back easily if you choose.

Sit close to your workstation.

Your feet should be flat on the floor or on a footrest.

Keyboarding and mouse operation should be achieved comfortably without stretching.

WARRANTY

Control is warrantied for 10 years including in multi-shift and 24-hour situations.

The recommended maximum user weight is 160kg.

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

CHAIR CARE

The **mechanical parts** of your Control chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The **gaslift** contains pressurised gas and should not be tampered with in any way.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.