


HOW TO ADJUST YOUR TAG CHAIR

BACKREST HEIGHT

Loosen the knob at the rear left of the mechanism, and slide the backrest to the desired position.

 Tighten the knob to fix in place.

REAR
RIGHT LEVER

BACKREST ANGLE

Lift lever to allow the backrest to tilt.

Lower the lever to fix the angle.



 LEFT
LEVER

SEAT ANGLE

Lift lever to allow the seat to tilt.

Lower the lever to fix the seat angle.

FRONT
RIGHT LEVER

GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.

Take your weight off the seat and lift lever to raise the gaslift.

EDEN

TAG 3.30/3.40

Keep this for
later reference



10YR

WARRANTY:
FOR NORMAL
OFFICE USE

140KG

RECOMMENDED
MAXIMUM
USER WEIGHT



GREENGUARD
GOLD CERTIFIED*

*Product Certified for Low Chemical Emissions: UL.com/GG UL2818

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust your backrest height so that the lumbar support fits into the lumbar contour of your back.

Adjust your backrest angle, seat angle, and seat height to a position that allows you to sit close to your workstation.

Your feet should be flat on the floor or on a footrest. There should be no pressure under your thighs.

Keyboarding and mouse operation should be achieved comfortably without stretching.

WARRANTY

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure on Tag chairs. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

CHAIR CARE

The **mechanical parts** of your Tag chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The **gaslift** contains pressurised gas and should not be tampered with in any way.

The **foam and standard fabric** used in the upholstery of Tag chairs comply with standard AS/NZS 4088.1:1996.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.

This chair is covered in:

- Polyester fabric
- Other