

HOW TO ADJUST YOUR TEMPO CHAIR



RATCHET BACK LIFT

BACKREST HEIGHT

Click backrest upwards with both hands till it reaches the desired height.

(When it reaches the top of the 8 ratchet positions it will return to the bottom of the range.)

REAR
RIGHT LEVER

BACKREST ANGLE

Lift lever to allow the backrest to tilt.

Lower the lever to fix the angle.

FRONT
RIGHT LEVER

GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift.

Take your weight off the seat and lift lever to raise the gaslift.

LEFT LEVER

SEAT ANGLE

Lift lever to allow the seat to tilt.

Lower the lever to fix the seat angle.

EDEN

TEMPO 3.40/3.50

Keep this for
later reference



10YR 10-YEAR
WARRANTY

140KG RECOMMENDED
MAXIMUM
USER WEIGHT



GREENGUARD
GOLD CERTIFIED*



100%
Wood from well-
managed forests
FSC® C182102

*Product Certified for Low Chemical
Emissions: UL.com/GG UL2818

WARRANTY

Tempo is warrantied for 10 years in normal commercial-use situations.

The recommended maximum user weight is 140kg.

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust your backrest height so that the lumbar support fits into the lumbar contour of your back.

Adjust your backrest angle, seat angle, and seat height to a position that allows you to sit close to your workstation.

Your feet should be flat on the floor or on a footrest. There should be no pressure under your thighs.

Keyboarding and mouse operation should be achieved comfortably without stretching.

CHAIR CARE

The **mechanical parts** of your Tempo chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The **gaslift** contains pressurised gas and should not be tampered with in any way.

The **foam and standard fabric** used in the upholstery of Tempo chairs comply with standard AS/NZS 4088.1:1996.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.