

HOW TO ADJUST YOUR CONTROL CHAIR

AFRDI
CERTIFIED
FOR USERS UP TO
160KG
MULTI-SHIFT
USE

REAR
RIGHT LEVER

SEAT ANGLE

Turn forward for
a forward tilt seat
position.

Turn back for a
level seat position.

ROUND
RIGHT HANDLE

SEAT/ BACK TILT TENSION

Turn backward to
increase tension.

Turn forward to
lighten tension.

FRONT
RIGHT LEVER

GASLIFT SEAT HEIGHT

When sitting, lift lever to lower
the gaslift.

Take your weight off the seat
and lift lever to raise the gaslift.

ADJUSTABLE HEADREST

Slide up to adjust height.
Twist in or out to adjust angle.

HEIGHT-ADJUSTABLE
ARMRESTS

Use button on side of
armrest to adjust height.

ROUND
LEFT HANDLE

SEAT/ BACK SYNCHRO TILT

Turn forward
to release
seat/back
synchro tilt.

Turn
backward
to lock in
desired
position.

FRONT
LEFT LEVER

SEAT SLIDE

Take your weight
off the seat, lift lever,
and slide seat forward
or backward to
adjust position.



EDEN

CONTROL



| | |
|--|--|
| 10YR | 10-YEAR WARRANTY |
| 160KG | RECOMMENDED MAXIMUM USER WEIGHT |
| 24HR | SUITED FOR 24-HOUR USE |
| AS/NZS 4438: LEVEL 6 AFRDI CERTIFIED | AUSTRALIAN / NZ STANDARD FOR COMPUTER CHAIRS |
| 160KG CERTIFIED AFRDI RATED LOAD | AFRDI 142 CERTIFIED FOR 160KG MULTI-SHIFT |

WARRANTY

Control is warrantied for 10 years including in multi-shift and 24-hour situations.

The recommended maximum user weight is 160kg.

Eden Office accept full responsibility for faulty workmanship and/or mechanical failure. Chair parts will be repaired or replaced free of charge within this period.

Repairs undertaken by any other party, or adjustment or tampering with mechanical parts, could void the warranty.

SEATING POSTURE

We recommend computer users adopt an open-angle sitting position, with knees slightly lower than hips.

Always sit near the back of your seat.

Adjust the tilt tension so that when the synchro tilt is released the chair supports your weight in an upright seated position but allows you to lean back easily if you choose.

Sit close to your workstation.

Your feet should be flat on the floor or on a footrest.

Keyboarding and mouse operation should be achieved comfortably without stretching.

CHAIR CARE

The **mechanical parts** of your Control chair require little or no maintenance.

The **castors** should be kept clear of threads or other objects that would inhibit their movement.

The **gaslift** contains pressurised gas and should not be tampered with in any way.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning: Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.